

3 cu.ft.

NeoMix Original Admixture accelerates set time, increases strength, and reduces cracking of concrete countertops.

DIRECTIONS

NOTE: For complete instructions, refer to Fu-Tung Cheng's NeoMix Concrete Countertop Instructional Video.

- Wear a dust mask before starting the mixer. Place six, 60 lb. bags of Quikrete 5000 or Pakmix Super 5000 into mixer.

 Add contents of this package. If fibers are clumped together, break them apart with your fingers. (Wear gloves as the
- cement powder may irritate exposed skin.) Mix the dry ingredients thoroughly for up to 30 seconds.

 Keep the mixer running and add NeoMix Water Reducer and water mixture by sloshing it in from a bucket.

 CAUTION: Never reach into a moving mixer!
- Mix thoroughly before pouring into the mold.

ATTENTION: Refer to warning label for detailed cautionary information.

Copyright 2003, Product of Cheng Concrete Exchange, a division of Cheng Design. Visit concreteexchange.com.